





### Storage

The boards must be transported and laid on a flat surface in a clean and dry place, protected from direct moisture.

Pallet handling on site will be performed with the necessary care. Bumps at the corners of the pallets can cause damage to the boards.

Store the boards indoor; boards must be not in direct contact to the ground and protected from moisture and atmospheric agents. During the storage of pallets on site, make sure to not remove the plastic wrapping. The boards must be dry at the time of installation as the place on which they are going to be installed.

The boards have one side that should be placed against the structure (back of the board). The back of the board usually has CELENIT logo.

In the absence of the logo it is possible to identify the front according to the pallet's layout: the front of the boards is towards the top and the back down towards the pallet.

If the boards were for indoor use, before installation they must remain in the room to adapt to the temperature and humidity, for a few days. Avoid sudden temperature increases, just after the application of the boards.

